MID-GEORGIA SOARING ASSOCIATION K-21 / G-102 BEFORE TAKEOFF CHECKLIST

****Before pushing out on runway****

- Tail dolly off
- Belts, harness confirm both cockpits
- Altimeter set both cockpits
- Airspeed 0 both cockpits
- Master switch on
- Avionics on, volume set
- Radio on, volume set, frequency set
- Flight controls check full travel both cockpits
- Trim set
- Wind check
- Brief emergency plan

**** After pushing out on runway****

- Radio check with Pawnee
- Canopies closed, locked, PUSH (Rear, then front)
- Red tape inspected in tow rope viewing window
- After rope hookup maximum wheel brake on, then thumbs up

****Start of takeoff roll****

Spoilers – closed and locked